

FAKTABLAD S4100 & S3100

			COOLPIX S4100	COOLPIX S3100	
Effective pixels		14.0 megapixels			
Image sensor		1/2.3-in. type RGB CCD			
Lens		Optical 5x zoom, NIKKOR lens			
	Focal length	4.6-23.0mm (35mm [135] format equivalent to 26-130 mm)			
	Aperture	f/3.2-6.5			
	Lens construction	6 elements in 5 groups			
Digital zoom		Maximum 4x (35mm [135] format equivalent to approx. 520 mm) [T.B.A.]			
Focus range (from lens)		Approx. 50 cm (1 ft. 8 in.) to infinity (at wide-angle setting), approx. 80 cm (2 ft. 7 in.) to infinity (at telephoto setting), Macro mode: approx. 10 cm (3.9 in.) to infinity (at wide-angle setting)			
Vibration Reduction (VR)		Electronic type (for still images and movies)			
	Other blur-reduction functions	Motion Detection , BSS (Best Shot Selector)			
ISO sensitivity (Standard output sensitivity)		ISO 80, 100, 200, 400, 800, 1600, 3200 (4320 x 3240), Auto (ISO 80 to 1600), Fix range auto (ISO 80 to 400, ISO 80 to 800) [T.B.A.]			
LCD monitor		7.5 cm (3-in.), approx. 460k-dot, TFT LCD monitor (HVGA), [Resistive touch panel] with Clear Color Display, anti-reflection coating and brightness adjustment		6.7 cm (2.7-in.), approx. 230k-dot, TFT LCD monitor (QVGA) with anti-reflection coating and brightness adjustment	
Storage media		Internal memory (approx. 20 MB) [T.B.A.]		Internal memory (approx. 45 MB) [T.B.A.]	
		SD/SDHC/SDXC memory card*1 [T.B.A.]			
Smart Portrait System	Face-priority AF/max. number of faces to be detected	12	Face priority, Face-priority AE, Face Zoom-in		
	Skin Softening	•	During shooting/playback		
	Smile Timer	•	Up to three smiling faces can be detected, can be switched ON/OFF		
	Blink Proof	•	Takes two sequential shots, can be switched ON/OFF		
	Blink Warning	•	Can be switched ON/OFF		
	In-Camera Red-Eye Fix	•	Automatically corrects red eye digitally, pre-flashes		
Subject Tracking*2*3		•	Auto lock-on: not available/AF activation: available/Tracking Restart: not available		

^{*1} Excludes Scene Auto Selector *2 Depends on power supply from PC *3 Based on CIPA Standards for measuring life of batteries *4 Based on CIPA Guidelines, DCG-005-2009



FAKTABLAD S4100 & S3100

		COOLPIS S4100	COOLPIX S3100		
Scene modes		[Q081750 19 scene modes*1, [Q08185] 18 scene modes*1 (Portrait, Landscape, Sports, Night portrait, Party/indoor, Beach, Snow, Sunset, Dusk/dawn, Night landscape, Close-up, Pet portrait, Food, Museum, Fireworks show, Black and white copy, Backlighting, Panorama assist, Paint (Q08175 only)			
	Scene Auto Selector	6 scene modes + Auto mode (Portrait, Landscape, Night portrait, Night landscape, Close-up, Backlighting)			
Sport Continuous mode*4		_			
Movie		HD 720p: 1280 x 720 (30 fps), VGA 640: 640 x 480 (30 fps), QVGA 320: 320 x 240 (30 fps)			
	HS movie	_			
D-Lighting		•			
Active D-Lighting		_			
Color Options		•			
Quick Retouch		•			
Slide show		Built-in; No music: Image effects: 3 kinds	No music or image effect		
File-sorting functions		Auto Sort mode, Favorite Pictures playback, List by date mode			
Battery charging with USB		With supplied charging AC Adapter: approx. 2 h 10 min charging time When camera is connected with powered on PC*2 via supplied USB cable: approx. 2 h 20min charging time			
Interface/Direct print compatibility		Hi-Speed USB/PictBridge			
Supported languages		26 languages			
Projector		-			
Power sources		Rechargeable Li-ion Battery EN-EL19 (700 mAh) , AC Adapter EH-62G (option)			
Number of life)*3	of shots per charge (battery	Approx. 190 frames with EN-EL19	Approx. 220 frames with EN-EL19		
Dimensions (W x H x D)		Approx. 95.0 x 56.8 x 19.9 mm/3.7 x 2.2 x 0.8 in. (excluding projections)	Approx. $93.5 \times 57.5 \times 18.4$ mm/3.7 x 2.3×0.7 in. (excluding projections)		
Weight*4		Approx. 131 g/4.7 oz. (including battery and SD memory card)	Approx. 118 g/4.2 oz. (including battery and SD memory card)		

^{*1} Excludes Scene Auto Selector *2 Depends on power supply from PC *3 Based on CIPA Standards for measuring life of batteries *4 Based on CIPA Guidelines, DCG-005-2009

Kontaktinformation

För pressbilder, vänligen besök http://press.nikon.se För övrig information, se www.nikon.se eller vänligen kontakta Irena Strozyk, Marknadsansvarig på Nikon telefon 08-594 109 04, 0709-95 58 25 eller e-post strozyk@nikon.se